

UB-5825
Panaboard

- ____ Built-in printer for easy-operation (plain paper)
- ____ Two-Panel Operation
- ____ USB PC Interface
- ____ 15 seconds per sheet copy speed
- ____ Can be wall-mounted or used with floor-stand option
- ____ Delivered with markers (black, red and blue) and one thermal transfer film



Electronic Copy Board

Input

Panel Dimension (mm)

| | |
|------------------------|--------------|
| Height | 900.0 |
| Width | 1762.0 |
| Panel Surface | 2 |
| Scanning System | Image sensor |

System Requirements

| | |
|------------------|--|
| Computer | IBM® PC/AT or compatible machine with a CD-ROM drive |
| CPU | Pentium®II or higher processor |
| Interface | USB 1.1 (B connector) |
| OS | Windows® 98/Me/200/XP |
| Memory | Windows® 98/Me 64 MB or more, Windows® 2000 128 MB or more, Windows® XP 256 MB or more |
| HDD | At least 40 MB free space (except saving space for image file) |

General

Dimensions (mm)

| | |
|--------------|--------|
| Width | 1735.0 |
| Depth | 212.0 |

| | |
|--------------------|--------|
| Height | 1344.0 |
| Weight (kg) | 27.0 |

Power Supply

| | |
|--------------------|----------------------------|
| Herz (Hz) | 50 - 60 Hz |
| Voltage (V) | AC 100-120V or AC 220-240V |

Power Consumption

| | |
|--------------------|--|
| Operational | 1.40 A (AC 100-120V) 0.75 A (AC220-240V) |
|--------------------|--|

Operating Environment

| | |
|--------------------|-----------------|
| Temperature | 10-35 degrees C |
| Humidity | 30-80% RH |

| | |
|-----------------------------|---|
| Standard Accessories | Markers (black,red,blue) Eraser Software CD-ROM Installation manual Operating Instructions Wall mount kit (Upper, lower) |
|-----------------------------|---|